



NORTH AMERICAN ARMS®, INC.
“Owner’s Instructional Manual”
“SIDEWINDER”



.22 Magnum “Sidewinder” Replacement Parts List

**(Requires Factory Installation)*

1	4100-1	*SW Machined Frame	12	1250	Index Spring
2	4130-1	*SW Barrel	13	1403	*Trigger
3	1409	Bead Sight	14	1405	Trigger Spring
4	4130-2	SW Crane Pivot Screw	15	1401	Trigger Pin
5	1140	Main Screw	16	1407	Bolt Pin
6	2600	*SW Shroud Set	17	1510	Grip Screw
7	1120	*Side Cover	18	GST-M	Wood Grip Set (Mag)
8	2220	*Cylinder Hand (Mag)	19	1406	Main Spring
9	1230	Hand Spring	20	2402	Bolt Spring
10	1210	Hammer	21	1401	Cylinder Bolt
11	1240	*Index Pin	22	4400-AS	*SW Cylinder Assembly

*For replacement parts pricing, check our web site at:
www.NorthAmericanArms.com*

NORTH AMERICAN ARMS®, INC
 2150 South 950 East • Provo, UT 84606-6285
 800-821-5783 or 801-374-9990
www.NorthAmericanArms.com

⚠ WARNING: This product contains (one or more) chemicals including lead, known to the State of California to cause (Cancer and) birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov
(Wash hands after handling)

This is an addendum to the NAA® .22 mini-revolver “Owners Instructional Manual”. Please make sure to review both; while many of the features of the “Sidewinder” are the same, there are some design differences that owners should be aware of for proper and safe use of the NAA® “Sidewinder”

*North American Arms®, Inc. Mini-Revolvers
 “Sidewinder” .22 Magnum*